

iFix Alarms

iFix alarms from the Silicon should always be taken seriously. They are partly dealt with by the process systems operator and partly by the shift crew with the help of the Silicon Main Pager Carrier.

- 1) First four alarms on Alarm Summary are CAEN power supply related (PS_LOGGING, PS_TRIP, PS_ALARM, PS_SMTH_OFF),
 - a) To be handled by shift crew → do not silence these alarms
 - b) Call control room (x2080) in case of questions
- 2) If you silence other alarms make an e-log entry and notify SciCo at X-2080 then take corrective action per procedures
- 3) ISL alarms permanently silenced: ISL_TE_CCW2L6_1OUT (broken temperature sensor)